

FLOOR-MOUNT TUB FILLER

SEPARATE ROUGH & TRIM

No need to worry about damaging the trim. Roughs for bath faucets and shower valves can be purchased separately from Riobel trims.

Unique box design: the rough can be easily removed without opening the trim box.



FLOOR-MOUNT TUB FILLER CONCRETE FLOOR INSTALLATION BOX



WHAT TO FORESEE

Parallel to the bath

4"

Finished installation

INSTALLATION STEPS

- 1** Pour the concrete so that it is flush with the top of the box and the PVC pipe exits in the wall division.
- 2** Remove the tape and insert the rough on which you preinstalled the piping.
- 3** You are now ready to continue your project!